



# NEED TO TAP YOUR INTAKE MANIFOLD?

NO TOOLS  
REQUIRED



## THE GFB VAG MK5/6 BOOST GAUGE TAP PROVIDES A NEAT & EASY MANIFOLD PRESSURE REFERENCE PORT FOR 2.0 TSI/FSI ENGINES

### EASY TO INSTALL WITH NO TOOLS AND COMPLETELY REVERSIBLE

- » 10 second installation!
- » Single clip-on part, ready to go straight out of the packaging
- » Uses a 1/4" hose barb that faces forward for better hose routing and to stop oil pooling in the bottom of the hose
- » Features two Viton O-rings which are impervious to oil, and a billet 6262-T6 aluminium body with a brass hose barb
- » Anodized black and laser engraved with the GFB logo, making it look right at home in the engine bay
- » Removal is simple and leaves no trace that it was ever installed
- » CNC machined and made in Australia under QMS ISO9001

### QUICK AND EASY INSTALLATION

1. SIMPLY DISCONNECT THE STOCK PCV HOSE
2. PUSH THE BOOST TAP INTO THE MANIFOLD FITTING
3. TWIST TO LOCK IT IN
4. RECONNECT THE PCV HOSE

FOR FITMENT  
INFORMATION  
SCAN HERE:



NORTH AMERICA  
Global Performance Parts  
[www.globalperformanceparts.com](http://www.globalperformanceparts.com)  
[sales@globalperformanceparts.com](mailto:sales@globalperformanceparts.com)  
Ph: 616 399 9025



THE ULTIMATE IN HIGH  
TECHNOLOGY PERFORMANCE



HEAD OFFICE / AUSTRALIA  
Go Fast Bits  
[www.gfb.com.au](http://www.gfb.com.au)  
[Sales@gfb.com.au](mailto:Sales@gfb.com.au)  
Ph: +612 9534 0099